


JP 注意: フル充電してからお使いください。また、同梱されている充電ケーブルをお使いください。ご使用後、きれいにしてから、保管してください。

1. ボタン表示





2. 加熱&振動モード

- *「(())」ポタンを1.5秒以上長く押すと、加熱&振動モードがオンになり
- *「🕢」ボタンを1.5秒以上長く押すと、加熱&振動モードがオフになり ます。

B. 加熱&振動モードの切替

(デフォルトモード1+5種の振動モード)加熱&振動ボタンを長く押す と、直接デフォルトモード1に入ります。デフォルトモード1は加熱と振動 が同時に始まります。加熱時間は3-6分です。6分後、加熱完了します。 (ご注意:加熱機能はデフォルトモード1だけにあります。他のモードに は加熱機能はありません。)

- * 再び「��」ボタンを短く押すと、5種の振動モードを切り替えます。 (ご注意:この5種の振動モードには、加熱機能はありません。)
- *「柳」ボタンを2回短く押すと、振動モードが中止になって、3分間続い て中止していると、振動機能は自動的にオフになります。 ・振動が中止している状態で、再び「∰」を短く押すと、前の振動モー ドに戻れます。



3.回転&ピストンモード

- *「▲」ポタンを1.5秒長く押すと、回転&ピストンモードがオンになり ます。
- * 「 \triangle 」 ポタンを1.5秒長く押すと、回転&ピストンモードがオフになり ます。

B.回転&ピストンモードの切替

*回転&ピストンモードがオンになっている状態で、再び「**Δ**」ボタンを 短く押すと、5種の回転&ピストンモードを切り替えます。

- * 「▲」ボタンを2回短く押すと、回転&ピストンモードが中止になりま す。3分間続いて中止していると、.回転&ピストン機能は自動的にオフ になります。
- *回転&ピストンが中止している状態で、再び「 \triangle 」を短く押すと、前の 回転&ピストンモードに戻れます。

4. モード強度調節

* いずれかのモードがオンになっている時、「 ● 」を前に押すと強度が 高くなります。逆に押すと強度が低くなります。


5. 表示状態

動作状態	常時点灯
ローバッテリー	点滅
充電状態	点滅
充電完了	常時点灯





1. Buttons Display



2. Heating and Vibrating mode

A. ON/OFF

A. ON/OFF

*Long press the ""()" button for 1.5s to turn the heating and vibration mode on, the device will enter mode 1 and start heating, it will take 3-6 mins for the device to heat up to the specified temperature.

*Long press the """ button for 1.5s to turn the heating and vibration mode off.

 Heating and Vibrating mode switching (1+5)
(Note: Heating only functions during mode 1, The other 5 modes activate vibration, and the device will not heat up whilst vibration is active).

After activating the Heating and Vibration mode, the device will enter the default mode 1, and the heating will reach the specified temperature within 3-6 minutes,

if you press the "o" button, it will stop heating and enter the vibration mode, press the ""(()" button again to switch between the 5 vibration modes, double-click the "(()" button to pause the vibration mode you have currently selected, (If the pausing lasts up to 3 mins while the rotating mode is off, the product will automatically shut down.) click again to return to the previous state.



3. Rotating mode

*Long press the "**\Delta**" button for 1.5s to turn on the rotating mode, the device will enter the default rotating mode. Long press the "**\Delta**" button for 1.5s to turn the rotating

B. Rotating mode switching

*Once on, press the "\$\Delta\$" button to switch between 4 rotating modes, double-click the "\$\Delta\$" button to pause the rotating mode, (If the pausing lasts up to 3 mins while the vibrating mode is off, the product will automatically shut down.) click again to return to the previous status.


4. Adjusting mode intensity

 st When any mode is on, slide the switch(lacktriangle) up and down to adjust mode intensity.

5. Status Display

Activating status	Lasting light
Low battery	Light flashes
While charging	Light flashes
Fully charged	Permanent light

ZEMALIA



トルネードカップ 製品説明書 Product Manual